

Projector User Guide

1. Turn on the projector using the remote.
2. Place laptop on the closest table and turn on. Do not place the laptop so far away that the cable stretches above the ground.
3. Look at your laptop to determine if you need a VGA or HDMI Cable.
4. Plug one end of the cable into the laptop.
5. Plug the other end of the cable into the appropriate port in the wall.
6. If you need sound and you're using VGA, plug the audio jack attached to the cable into the VGA audio port in the wall. If you are using HDMI you do not need a separate audio input/output.
7. Plug the other end of the audio cable into the laptop.
8. You should now see your display on the whiteboard.

NOTES:

This is a "short throw" projector. You may notice the edges of the display image are slightly curved. This is normal.

Replacement batteries for the remote are available at the Reference Desk.

When you are finished please

1. Turn off the projector.
2. Disconnect cable, recoil it, and return it to correct place in the cabinet.
3. Return remote to the cabinet.

