

I want to use a microphone.

Go to circulation desk and ask for microphones. If you have a library card you will check them out on your card. If you don't have a card you must leave identification until the microphones are returned.

Microphone volume cannot be adjusted.



Wired Microphones

1. Plug the cable into any of the three wall microphone jacks at the front of the room. Make sure to line up the prongs correctly.
2. Use the PUSH button to fully engage the plug and to release it.



Wireless Microphone

1. To turn on, hold down the power button (button says "mute") on the mic until the green dot lights up.
2. After use hold down the power button to turn off.



Lapel Microphone

1. To turn on, hold down the power button (button says "mute") on the top of the battery pack until it lights up green.
2. Clip to clothing.
3. After use hold down the power button to turn off.